



Finding the MAC Address for your device

Xbox (One & 360)

Xbox One:

1. Sign in to your profile.
2. Select **My Games & Apps**.
3. Select **Settings**.
4. Select **Network**.
5. Select **Advanced Settings**. The **Wireless MAC** Address will be displayed on the right-hand side of your screen.

XBOX 360:

1. On your console, go to My Xbox, and then select **System Settings**.
2. Select **Network Settings**.
3. If prompted, select **GURegistered**.
4. Select **Configure Network**.